

The BIENFANG[®] De-Roller takes the curl out of prints and posters in minutes!

This first-of-its-kind accessory provides an ingenious solution to the curling problems plaguing framers. Now, by simply using De-Roller, you can take the curl out of posters, digital printouts, and photographic and fine art papers in minutes — without causing damage or wasting hours of your valuable time.

The process is safe, simple and much more efficient, allowing framers to increase productivity without risk.

Two Models, for art that is safely and permanently uncurled and ready to mount

DR 100 is recommended for photographic and coated papers. It is available in both 24" and 50" widths.

DR 150 is recommended for posters, digital printouts and fine art papers. It is available in both 24" and 50" widths.

De-Roller Quality Features

- Designed to get the curl out of papers that come off a roll or are stored or shipped in tubes.
- Achieve the desired flat sheet profile in just a minute or two.
- Eliminates the possibility of creasing or damage during the unrolling process.
- Timesaving, most effective alternative to flattening with glass or metal weights.
- Highest quality construction utilizes durable thermoplastic film and strong metal core.
- Friction strips hold art securely in place during the de-rolling process.
- Papers may be de-rolled prior to or after printing with no dry time needed for inks.
- Works safely on any flat, clean surface.
- Easy to use, keep clean, and store.
- Made in the USA. Patent pending.




BIENFANG® De-Roller®

Model	Width	Diameter
DR 10024	24"	1"
DR 10050	50"	1"
DR 15024	24"	1 1/2"
DR 15050	50"	1 1/2"

How to use the De-Roller

Step 1

Unroll on flat clean surface larger than the De-Roller, with tube near table edge.




Step 2

Place curled paper on film next to tube and press down as you roll tube forward, maintaining pressure at all times.



Step 3

Once end of paper is reached leave it rolled up for a few seconds, then roll tube back towards you to its original position.



Step 4 (optional)

If necessary turn paper from front to back and repeat the process. For prints longer than film, turn 180 degrees and de-roll from opposite sides.



Bienfang Framing Products

A division of Elmer's Products, Inc.
2020 West Front Street
Statesville, NC 28677

Customer Service: 800-873-4868

Technical Service: 888-240-6021

Tech. Fax: 704-871-8671

Hrs: 8:00 a.m.-5:00 p.m. (EST)

www.elmers.com

www.forframersonly.com

©2007 Elmer's Products, Inc.